


1 Location of the Data Link Connector (DLC)

The DLC (Data Link Connector or Diagnostic Link Connector) is the standardized 16-cavity connector where diagnostic scan tools interface with the vehicle's on-board computer. The DLC is usually located 12 inches from the center of the instrument panel (dash), under or around the driver's side for most vehicles. If Data Link Connector is not located under dashboard, a label should be there telling location. For some Asian and European vehicles, the DLC is located behind the ashtray and the ashtray must be removed to access the connector. If the DLC cannot be found, refer to the vehicle's service manual for the location.





2Diagnostic Trouble Codes (DTC) that identify which section of the emission control system has malfunctioned



OBDII/EOBD

Generic OBDII Diagnostics

The OBD II Diagnostics function is a fast-access option that allows you to carry out a quick test on the engine system of OBD II vehicles





Vehicle diagnosis



If the manufacturer of your vehicle is not listed, use the **UP/DOWN** scroll button to select **Other** and press the **OK** button.









Review



Reset



3 Setings



Help



Register code





Software Update

This function allows you to update the scan tool software through a computer.

www.dbscar.com

If you are a new user, slide right arrow next to Register to enter registration page





If you have registered to be a member, input your name/CC and password in Fig. 3-4, and then click the “Log In” button to enter the main menu screen directly

🔍 [Search](#) | [My account](#) | [Info](#) | [FAQ](#) | [Contact us](#) | [Help](#) | [Feedback](#) | [Privacy policy](#) | [Terms of use](#) | [Sitemap](#)




Welcome to log in

Username:

Password:

Remember me [Forgot your password?](#)

[New password?](#) [Forgot name?](#)



Download



